

Adhesive Recommendations



For all adhesives: Apply to clean surfaces. Test the glue, the rhinestones, and your method of application before committing to a large project.

For all glues used on fabrics: pre-wash garments when possible; after applying embellishments, hand wash; lay flat or hang dry; not intended for dry cleaning.

Rhinestones Unlimited offers these adhesives:

- O.K. To wash it – most fabrics.
 - * Not recommended for rayon, silk, satin, and satin ribbon. Let dry 24 hours.
- Flexible Stretchable – stretchable fabrics and knits. Let dry for 24 hours, however we recommend letting dry for 72 hours.
 - * Not recommended for swimwear.
- Jewel It – fabrics, glass and metals. Let dry 24 hours.
- Fabri-Tac – fabric, lace, trim, leather, and wood.
 - * Not recommended for varnished woods or for attaching acrylic rhinestones.
- Gem-Tac – fabric, wood, suede, glass, vinyl and metal. Let dry for 24 hours.
- Devcon 2-part Epoxy – for household, industrial crafts, wood, glass, tile, metal, ceramic, rubber, leather, or any job that requires a high-strength, high-quality bond. Sets in 5 minutes, full bond strength in 1 hour.
 - * Not recommended for fabric or for attaching acrylic rhinestones.
- E6000 – fabrics, wood, glass, plastic, tile, metal, ceramic, cement, rubber, vinyl, leather, or Styrofoam. Sets in 10 minutes, bond sets 2–6 hours. Full strength after 24–72 hours.
 - * Not recommend for attaching acrylic rhinestones.



www.RhinestonesU.com
1-800-340-3525 or 952-848-0133