

Make Your Own Barrettes

- Use 3-row 20ss banding or 2-row 29ss metal set banding.
- You'll need 2.5" of banding per barrette.
- Lay the banding on top of a barrette, cut the banding to fit the barrette.
- Unfasten the barrette so glue does not seep into it and glue it shut.
- Run a line of glue along the metal bars of the barrette. We recommend either Devon 2-part epoxy or E6000. Some people say Gem-Tac also works.
- Lay banding on top of barrette.
- Lay barrette, banding side down, making sure nothing shifts, until glue dries.



Rhinestone Unlimited's barrette forms.



www.RhinestonesU.com
1-800-340-3525 or 952-848-0133